I'm not a bot

Locate the TV's buttons, usually on the bottom under the LG logo. On older LG TVs, press the Input button to switch between them. On newer models, press the Power button to open and navigate the menu, select Inputs, and switch between them. 1 Search for your LG TV's buttons. LG tends to place them along the bottom of the set, directly under the LG logo. [1] On some models, the buttons are located along the bottom-right rear side. 2 Power on your TV. Find the power button, and press it to power on the TV set. If your power button is broken, you can hold down one of the volume or channel buttons for a few seconds to power on the TV. Advertisement 3 Determine which button is the input button. Most LG TV models feature six buttons: a power button, a volume-up button, a volume-down button, a channel-up button, a channel-down button, and a menu button. On newer models, the power button doubles as the input button. [2] Older LG TV models also have an input button. It is likely to be either the leftmost or rightmost button. If your TV has one, using it to switch inputs is the simplest method of doing so without a remote. A few models feature a joystick that allows you to toggle between inputs, although this is less common. You can find your TV's exact settings and button alignment by consulting [its manual| . 4 Tap the power button repeatedly. Tapping the power button once opens a menu of your TV's display inputs. Tap the button repeatedly to cycle through the different options. Hold it down longer to select the input you need. Be careful not to hold the power button down too long, as this will power off your TV set. This might present a difficult learning curve at first, but you should get the proper timing down soon enough. Advertisement 1 Download the LG ThinQ app. The app is available for free on the App Store for iPhone users and on the Google Play Store for Android users. Its logo is a white house against a red background. Keep in mind you must have an LG Smart TV to use the app with your TV 2 Power on your TV. Using the power button on the bottom/rear of your TV, turn the TV on. Also ensure that your TV and smartphone are connected to the same Wi-Fi network. If this is your home Wi-Fi, you likely configured your TV to be on that network when you first set it up. [3] 3 Launch the ThinQ app and create an account. You may create an LG account through Google or Facebook, or through a separate email address. You may also sign in if you have used the app previously. 4 Tap the + Add a Device button. It should be located atop the app's homepage, as well as in the center if you have not added any devices already. 5 Read the prompts that appear on your phone screen, then tap “OK.” This information is mostly on how you can use the app, and with which devices it is compatible. 6 Open the Home Appliances section in the app, then select “TV.” Your phone will now start searching for nearby LG Smart TVs. 7 Choose your TV. It may take a few seconds for it to appear as an option, so don’t worry if you don’t see it right away. 8 Enter the verification code from your TV screen. This 8-digit code will appear in a blue box at the center of the screen. 9 Tap “Move to Home.” Now that it's connected to your TV, the app will function as a remote. 10 Tap "Input" on your virtual remote. Now that your app is functioning as an LG TV remote, you can simply click the "Input" button to cycle through your TV's inputs. You can also click the icon of a house on the ThinQ app's homepage to access your TV's settings and change the input. Advertisement 1 Find a wireless mouse. If you have a wireless mouse handy, you can use it to control your LG TV! 2 Plug the mouse's sensor into the TV's USB port. The port should be at the back of the TV set, in line with the HDMI ports. 3 Power on your TV. Press the power button at the bottom/rear of the TV set. 4 Press the input button. This will pull up a menu of your TV's display inputs. 5 Use the mouse to select an input. It may feel a bit strange at first, but you can use your mouse to select and click on your desired input. [4] You can also use your mouse to switch channels, or connect your TV to Wi-Fi if it is a Smart TV. Consult your TV's user manual for more details! Advertisement Ask a Question Advertisement Thanks for reading our article! If you’d like to learn more about fixing your tv, check out our in-depth interview with Adam Paris. Co-authored by: Audio & Visual Installation Expert This article was co-authored by Adam Paris and by wikiHow staff writer, Cory Stillman. Adam Paris is an AV Expert and the Owner of Bat City TV in Austin, Texas. With over five years of professional experience, Adam specializes in installing audio and visual equipment such as TVs and sound systems. Adam received his degree from Austin Community College. This article has been viewed 299,239 times. Co-authors: 7 Updated: February 24, 2025 Views: 299,239 Categories: Basic Computer Skills Print Send fan mail to authors Thanks to all authors for creating a page that has been read 299,239 times. Smart TVs have proven to be a great choice for just about anyone looking to get a new TV. No longer do you actually need to get separate devices, such as a Roku TV, Apple TV, or Fire TV, since now you can just get the apps through your TV instead. There are a lot of smart TV creators, including by Roku, but also by LG. However, for a lot of LG TV owners, they have trouble figuring out where the power button is on their LG TV. While the power button can be located on a lot of spots on a TV (side, bottom, even on the back at times), LG TVs that have power buttons typically place the button on the LG TV right below the LG logo and on the bottom of the TV. But does the LG TV have just a power button on it? Which LG TVs have a power button? And what do you do if your LG TV is not powering on at all? Televisions have often had buttons on them at varying spots, though more recently, buttons have been limited, or sometimes removed altogether. Thus, it may make people wonder whether their LG TV even has a way to power it on with the TV itself. If your LG TV is one of the TVs to have a power button, it will usually be found on the bottom of the television in the middle, below where the LG logo is located. Unfortunately, this may not always be the case, as some LG TVs may not have a power button at all. In this case, the only thing you can do to power your LG TV on or off would be to use a remote or a digital app. If you cannot find a power button on your LG TV, refer to your TV’s user manual to see if you are just missing it or not. While the power button is arguably the most important button on a TV, it is far from the only one you would expect or want to have. Other common buttons you might want on your television include volume, channel changing, menu, and input. The first two are self-explanatory, while the other two need a little more detail. The menu has a number of settings, and these settings may vary from television to television. Common settings include brightness, contrast, closed captioning, screen size, and more. Meanwhile, the input function switches between different inputs. That is, things generally (but not exclusively) connected to the TV via HDMI cables. While newer LG TVs that have a power button typically lack these other buttons, that should not be taken to mean that the TV is unable to perform these functions on its own. Some LG TVs are able to do all of these with just the use of the LG TV’s power button. To do this, while powered on, tapping the power button brings up a menu of options (Power Off, Inputs, Volume Up, Volume Down, Channel Up, and Channel Down). Pressing it again switches to one of these options. Once you get to the option you want, you can select it by holding it. More than a few people have experienced frustration with not having any buttons on their TVs at all. When you lose your remote, it can be a difficult thing to be able to use your television. But why do TVs do this? It’s somewhat hard to say, as the manufacturers don’t really go into great detail about why they cut down on features. Some possible reasons, however, may have to do with making the TV look more aesthetically pleasing and streamlined, making them cheaper to produce, and more cynically, justify people buying more remotes to buy them if theirs is lost or broken. One annoyance with an LG TV that has no power button is that, if you do not have any external method of powering off (such as a remote), the only way you can power off the TV altogether would be to unplug it from the power source. Otherwise, your next best bet would be to simply allow the television to go into low-power mode, which is better than wasting more power but still worse than wasting none. Normally, a person would power their TV off with either the power button on the LG TV itself (where applicable), or on the device they are using to control it. There are three common types of devices that may be used to do this. The first is the remote that the television comes with. With certain televisions, they may have a more simplified remote layout designed especially for that TV (such as Roku with its Roku Remote). Next, you can use an app on your phone or tablet that is meant to link to your TV and control it that way. LG TV is no exception to this, and you can get an app on both the Google Play Store and Apple’s App Store. Your last option would be to buy a replacement remote, typically a universal remote. This kind of remote confers a lot of advantages, such as being able to be used with multiple TVs and simply having a lot more functionality than many other remotes. All three of these devices can often be used by themselves to offer a complete control experience, though having all three at your disposal couldn’t hurt. Some may have found a way to power on their TV, only to find that the TV doesn’t respond. In this case, check that the cable is plugged in at both ends and that the device you are using to power it on has power as well. If you’ve verified that it should be working, consult with LG about a possible repair or replacement. Yes, LG TVs have buttons on them. Depending on the type of LG TV you have, the buttons can be physical or virtual. Physical buttons can typically be found on the back or on the side of the TV, or within the detachable remote. This can include buttons such as power switch, volume control, channel selector, input selectors, and more. Virtual buttons are located within the on-screen menu on certain models such as LG Smart TVs. These virtual buttons can be used to control the TV settings, open additional menus and specific apps, and more. How do I use my LG TV without the remote? Using your LG TV without the remote is possible, but it will require some effort on your part. Depending on the model you have, you could use buttons located on the TV or utilize the TV’s Smartphone app if it is smart TV compatible. For most LG TV models, you should be able to control the TV without the remote by using the buttons located on the TV itself. You can generally use the channel, input and volume buttons to control the TV and access menu items. To access the TV’s menu you can press the menu button, to access various setting options such as the connection settings, click the settings button. If the TV is a smart TV, you can also control the TV with an LG smartphone app. On the app, you can access various settings, enter text and control the TV’s power and volume. Finally, if you cannot locate the remote and do not feel comfortable trying to use the TV’s buttons you may want to consider purchasing a Universal Remote Control to access all of the TV’s features. Are there manual volume buttons on LG TV? Yes, there are manual volume buttons on LG TV. Most LG TVs have volume buttons located either on the bottom or side of the TV, allowing you to easily adjust the volume with just a few clicks. Depending on the TV model, the volume control may be located on the upper right or upper left side, or along the bottom of the TV. There may also be a dedicated remote control with dedicated volume buttons, enabling you to control the sound levels without having to use the TV remote. Some models may provide a telescopic slider on the TV body to adjust the volume levels. Turning the slider adjusts the volume levels. Do all LG TVs have a power button? No, not all LG TVs have a dedicated power button. Some models of LG TVs have a button that is part of the remote control, allowing you to turn the TV on and off from the remote. Other models have a physical power button located either on the side or the bottom of the TV. To determine if your specific LG TV has a power button, consult the user manual or reach out to a customer service representative. Where are the buttons on my LG TV? The location of the buttons on your LG TV will vary depending on the model and type of television. Generally, if your TV is a newer model, the buttons will be located on the back or side panel of the TV, if it is a flat screen television. If your TV is an older model, the buttons may be located on the front bezel. If you are having trouble locating the buttons, you can try looking for an LG logo on the TV or referring to the user manual of your TV. Once you have located the buttons, they should be clearly labeled with their respective functions. If you cannot find the buttons or re-locate the user manual, LG provides support website, chat and phone options to assist you. Specifically, you can reference LG USA’s support page at . lg. com/us/support and contact them directly with any further questions at 1-800-243-0000. How can I turn my TV on without the power button? Depending on the make and model of your TV, there may be a few ways to turn it on without using the power button. One possible way is to check the TV’s user manual or the manufacturer’s website to see if there is a specific remote control button that can be used to turn it on. Many newer TV models come with a small remote control that is used to access certain functions on the TV, including powering it on. Additionally, some TVs can be powered on by plugging them into a power outlet. The power outlet switch may need to be manually toggled on in order to initiate power to the TV. Finally, many TV models come with an audio/visual input jack that allows audio/visual devices such as computers and game consoles to be plugged directly into the TV for automatic power up. Why is my LG TV not turning on? There could be several reasons why your LG TV is not turning on. First, you should check to make sure that it is plugged in and that the outlet is working. If the outlet is working, you may need to check the power cord to make sure that it is securely plugged in to both the wall outlet and the back of the TV. Additionally, you may want to check the power switch located on the back of the TV and make sure that it is in the ON position. If the electricity and the power switch seem to be working correctly, then you may want to check that the batteries in the remote control are working. If they are not, replace them and see if the TV turns on. If the TV still does not turn on, there may be an issue with either the software or the hardware. First, attempt to access the TV’s menu to see if you can turn it on from there. If you cannot access the menu, try unplugging the TV from the power source, giving it a few minutes, and then plugging it back in. This can help reset the TV’s software in some cases. If none of these solutions work, you may need to contact either the manufacturer or a professional technician to have the TV serviced. How do I start my LG TV? Starting your LG TV is quite simple. First, make sure your TV is plugged in and that you have all the necessary cables connected. If you are using an external device such as a DVD player or a streaming service, make sure that it is also connected properly. Then, press the power button on the remote or the TV itself. This will turn the TV on. If you are controlling the TV through an external device, you will need to launch the device by following the prompts on the screen. Once the TV is on, you will be presented with the main home screen. From here, you can access all the features, applications, and settings of your TV. You can also access external devices, such as cable boxes and DVD players, by going to the Devices menu. Finally, you can make all of your necessary adjustments in the settings. Here, you can turn on or off features, change the picture settings, and select the audio output. Once your LG TV is set up and all the necessary connections are made, you are ready to enjoy all the features your TV has to offer. Where is the power button on LG monitor? The power button on LG monitors is located on the underside of the monitor, in the bottom left-hand corner near the VGA and HDMI port. It should be labeled “On/Off” or “Power” and is usually a circular, gray/black button. To turn the monitor on, firmly press the button until you hear a slight click. When powering off, press the button in the same manner. Please be aware that if you are using an LG monitor with a removable base, you may need to first detach the base before you can press the power button. How do you change the input on a LG Smart TV without the remote? It is possible to change the input on a LG Smart TV without the remote, though it takes a few steps. First, you need to locate and press the ‘Input’ button on the TV itself. This should be located in the middle of the bottom half of the TV. Usually, it looks like a square with arrows pointing outward. Once you’ve pressed the input button, you will see a list of input options on the screen. To select the correct input, you need to use the arrow buttons located at the bottom of the TV. To navigate to the desired input, use the left and right arrow buttons. When you’ve located the desired input, press the central ‘OK’ button. That should allow you to change the input without the remote. If you find the TV unresponsive and you can’t get it to change the input, you may need to manually reset the TV. To do this, you’ll need to press the power button located on the back of the TV. Depending on the model, there may be a switch or a button. Push down the switch or hold in the button for a few seconds and then release. This should reset the TV and it should now respond. How do I change my LG TV back to HDMI? In order to change your LG TV back to HDMI, you must first identify the type of HDMI port you wish to connect your device to. Depending on the model of your LG TV, it may have an HDMI 1, 2 or 3 port. To determine the type of port on your TV, you can refer to your TV’s manual or model number. Once you have identified the port you wish to connect to, you can switch your TV back to HDMI. To do this, you will need to access your TV’s menu and select the input source option. Once you are in this menu, you can select the HDMI port that you have identified on your TV. Selecting this port should switch your TV back to the HDMI source. You may also need to enable the HDMI-CEC function. To do this, access your TV’s menu and select the system option. Here you will find an option for HDMI-CEC or EasyLink and it may need to be enabled in order for the HDMI connection to be established. Once you have enabled this option, you should be able to switch your LG TV back to the HDMI input source. If you are still having trouble switching your LG TV back to HDMI, you may need to check the cables and connections that you are using. Make sure that all the cables are plugged in securely and that all the connections are in working order. If everything appears to be connected properly, you may need to reset the TV. Refer to your TV’s manual for more information on how to do this. Why is HDMI not working on my LG TV? There could be several reasons as to why your HDMI port on your LG TV may not be working. The first thing to check is to ensure the correct HDMI cable is being used. Some cables are not compatible with all TVs, so you will want to verify it is the correct one. Additionally, you will want to check the ports themselves to make sure nothing is bent or broken and that they are clean of any debris, dust, or corrosion. You should also check your HDMI settings on the TV to make sure that it is not set to an incorrect port or that it is not disabled on the TV itself. Additionally, you will want to double-check that the HDMI cable is connected to the correct input on the TV and the correct output on your device. If all of the above is correct and the HDMI port still does not work, then you may need to test other appliances on the TV port to determine if the issue is with your device or the TV. If other devices work on the same port, then the issue lies with your device. Otherwise, the issue may be due to a broken port or board, and it may require service or repair. Where is HDMI on LG TV? On LG TVs, the HDMI port is typically located on the back of the device, usually towards the center-right side. Depending on the model, it could also be found on the side. It is usually identified with the HDMI logo and labeled with the port number (i. e. “HDMI 1”). Make sure that the device is unplugged before trying to locate the port. If you are having trouble finding the port, you could refer to your owner’s manual for more specific instructions. Can’t find the power button on my LG TV? If you can’t find the power button on your LG TV, there are a few things you should check. First, you should look at the remote that comes with your TV. Typically, the power button is located on the top or side of the remote. You may need to press the button with a pointed object for a few seconds for the TV to switch on. Alternatively, you may be able to use voice commands or certain features of your remote to power on the TV. Next, you should look at the back of the TV. You may find a power button on the back or side of the TV. Additionally, there may be a power button located on the back of your TV set that is designated solely for powering on and off. Again, you may need to press the button with a pointed object. If you cannot find the power button after searching your remote and the back of the TV, then you should consult the LG TV user manual. It should provide information regarding the exact location and function of the power button. Manuals are typically accessible online through the official LG website. How do you turn on a TV that has no buttons? If you have a TV that has no physical buttons to turn it on, then you may need to use a remote control or check if the power cable is properly plugged in. First, make sure that the power cable is plugged in to the wall outlet and then into the back of the TV. If you have a remote, press the TV power button or the power button on your cable or satellite box remote. If the remote is not working, check if the batteries are empty and replace them if so. If you do not have a remote, then you may be able to power it on with a universal remote. These are usually inexpensive and easily purchased online or at your local electronics store. In some cases, certain TVs may also have a power control switch on the side or back of the TV. If so, switch it to the “On”or “Power” mode, and it should turn on. LG TVs are known for their sleek design and advanced features, but if you’ve recently purchased one and are wondering where the input buttons are located, you’re not alone. With the evolution of technology, the placement of input buttons on modern TVs can sometimes be less intuitive than on older models. In this quick guide, we will explore where the input buttons are located on LG TVs, so you can easily switch between different devices and make the most out of your entertainment experience.Finding the input buttons is crucial for connecting external devices such as gaming consoles, Blu-ray players, or streaming devices to your LG TV. While older models typically had dedicated input buttons on the front or side of the TV, LG has embraced innovation and streamlined their designs. As a result, they have moved the input buttons to the rear panel or the remote control, making them subtly integrated into the overall aesthetic of the TV. In the following sections, we will detail the different ways you can access the input selection options on LG TVs, ensuring that you never miss out on your favorite content again.Location Of Input Buttons On LG TV Remote ControlThe remote control is an essential tool for operating an LG TV, and understanding the location of the input buttons is crucial for seamless navigation. On the LG TV remote control, the input buttons are usually located at the top or bottom of the device. These buttons may vary in appearance, but they commonly include icons such as a square, arrows, or an arrow within a circle.To access the input options, simply press the “Input” or “Source” button on the LG TV remote control. This will open up a list of available input sources, such as HDMI, USB, or AV. The exact layout and names of the input buttons may differ slightly based on the model of your LG TV.By pressing the input buttons on the remote control, you can cycle through the available input options until you find the one you want. This allows you to switch effortlessly between devices connected to your LG TV, such as gaming consoles, DVD players, or streaming devices.Familiarizing yourself with the location of the input buttons on the LG TV remote control will enhance your overall viewing experience and make it easier to access and manage various input sources.Exploring The Input Options On LG TV InterfacesLG TVs offer a wide range of input options to enhance your viewing experience. By exploring the input options on LG TV interfaces, you can easily connect external devices and access various features.One of the primary input options on LG TV interfaces is HDMI. HDMI ports allow you to connect devices like gaming consoles, Blu-ray players, and streaming devices to your TV. By using an HDMI cable, you can transmit high-quality audio and video signals, ensuring a seamless viewing experience.Another essential input option is the USB port. LG TVs have USB ports that enable you to connect devices such as external hard drives, flash drives, and digital cameras. This allows you to access and view multimedia files directly on your TV screen.Additionally, LG TVs provide options for connecting antennas and cable boxes. By connecting an antenna, you can access over-the-air channels, while a cable box enables you to enjoy cable TV channels.LG TV interfaces also feature auxiliary ports, such as composite and component ports. These ports allow you to connect older devices that may not have HDMI capabilities.Exploring the input options on LG TV interfaces opens up a world of possibilities for entertainment and connectivity. By understanding these options, you can make the most of your LG TV and enjoy a diverse range of content.Navigating The LG TV Menu To Access Input SettingsThe menu on an LG TV provides a wealth of options to customize your viewing experience, including accessing the input settings. To navigate to these settings, you will need to follow a few simple steps.First, ensure that your LG TV is turned on and the remote control is functioning properly. Then, look for the “Settings” button on your remote, which is usually represented by a gear or cog icon. Press this button to enter the settings menu.Once you are in the settings menu, use the arrow buttons on the remote to navigate and highlight the “Input” or “Input Settings” option. Press the “OK” or “Enter” button to select this option.Within the input settings, you will find various options to manage your input sources. Here, you can customize the labels for each input, enable or disable certain inputs, and even rearrange the input order according to your preference.Take your time to explore these settings and make any necessary adjustments to suit your needs. Once you have made your desired changes, simply exit the settings menu, and you will be ready to enjoy your selected input sources on your LG TV.Connecting External Devices To LG TV: Finding The Input PortsConnecting external devices to your LG TV is essential for expanding your entertainment options. To begin, you need to locate the input ports on your TV. These ports are typically located on the back or side of the TV, depending on the model.First, identify the type of device you want to connect, such as a gaming console, Blu-ray player, or soundbar. Common input ports on LG TVs include HDMI, USB, component, and AV ports. HDMI ports are the most common and versatile, allowing you to connect a wide range of devices with a single cable.Once you have identified the specific input ports you need, carefully plug in the cables from your external devices. Ensure that the cables are securely connected to both the device and the TV. Additionally, make sure to match the corresponding ports on both devices to avoid any compatibility issues.After connecting the devices, switch your LG TV’s input source to the corresponding input port. You can do this by using the input button on your remote control or navigating through the TV menu. Enjoy your newly connected external device and explore the enhanced entertainment options it provides!Troubleshooting Input Button Issues On LG TVsInput button issues on LG TVs can be frustrating, but they can often be resolved with a few simple troubleshooting steps. If you’re experiencing problems with the input button on your LG TV remote control, here are some solutions to try:1. Check the remote control: Make sure the batteries in your remote control are not dead or low. Replace them if necessary and try pressing the input button again.2. Restart the TV: Sometimes, a simple power cycle can fix input button issues. Turn off your LG TV, unplug it from the power source, wait for a few minutes, and then plug it back in and turn it on again. Test the input button to see if the problem is resolved.3. Reset the TV settings: If the issue persists, you can try resetting your LG TV to its factory settings. Go to the TV menu, navigate to the settings section, and look for the option to reset the TV. This will erase all your custom settings, so make sure to take note of any important configurations before proceeding.4. Update the TV software: Outdated software can sometimes cause input button problems. Check for any available software updates for your LG TV and install them if necessary. This can usually be done through the settings menu.5. Contact LG support: If none of the above solutions work, it’s best to reach out to LG customer support for further assistance. They may be able to provide specific troubleshooting steps or recommend a repair if needed.By following these troubleshooting steps, you can hopefully resolve any input button issues you may encounter on your LG TV and enjoy the full functionality of your device.Tips And Tricks For Managing Input Sources On LG TVsManaging input sources on your LG TV can be a breeze if you know a few tips and tricks. Here are some useful hacks to effortlessly handle your input sources:1. Customize Input Labeling: LG TVs allow you to rename your input sources for easy identification. Head to the Input Settings menu, select the input you want to label, and choose a name that suits your preferences. This feature is particularly useful if you have multiple devices connected to your TV.2. Reorder Input Sources: Is your Blu-ray player on HDMI 1, but you want it to be on HDMI 2 for convenience? LG TVs enable you to rearrange the order of your input sources. Simply navigate to the Input Settings menu, select “Edit,” and drag and drop the sources to your desired order.3. Assign Quick Access to Inputs: LG TVs provide a Quick Access feature that allows you to assign frequently used inputs to specific numbers on your remote control. This way, you can change inputs instantly by pressing the corresponding number on your remote.4. Remove Unused Inputs: If you have devices that are no longer connected to your TV, it is advisable to remove them from the input list. This declutters your interface and avoids confusion when switching between sources.5. Use the Input Button Shortcut: LG TVs usually have a dedicated Input button on the remote control. Pressing this button allows you to cycle through your input sources quickly. It’s a handy shortcut to access your desired input without navigating through menus.By utilizing these tips and tricks, you can effortlessly manage your input sources on your LG TV, ensuring a seamless and personalized viewing experience.Frequently Asked Questions1. Where can I find the input buttons on my LG TV?The input buttons on LG TVs are usually located on the remote control. Look for the button labeled “Input” or “Source” on your remote. Pressing this button will bring up a menu displaying all available input sources.2. Can I change the input source directly from the TV?Yes, you can also change the input source directly from the TV. Look for the physical buttons located on the side or bottom of your LG TV. These buttons are usually labeled with icons representing different input sources or numbered labels indicating the HDMI ports.3. How do I switch to HDMI input on my LG TV?To switch to HDMI input on your LG TV, simply press the “Input” or “Source” button on your remote control or TV until you reach the HDMI option. Use the arrow buttons or the number buttons on your remote to select the specific HDMI port you want to use.4. What if my LG TV doesn’t have an “Input” or “Source” button on the remote?If your LG TV remote does not have a designated “Input” or “Source” button, you can usually access the input selection menu through the “Home” or “Menu” button. Navigate through the menu options to find the input settings and select the desired input source.5. My LG TV has multiple HDMI ports. How can I switch between them?If your LG TV has multiple HDMI ports, you can switch between them by pressing the “Input” or “Source” button on your remote control or TV. Use the arrow buttons or number buttons to select the specific HDMI port you wish to use.Final VerdictIn conclusion, locating the input buttons on an LG TV is a simple task that can greatly enhance the overall viewing experience. By knowing where to find these buttons, users can effortlessly switch between different devices, such as gaming consoles, DVD players, or even streaming devices. This guide has highlighted the various ways to access the input buttons on LG TVs, including the remote control, the on-screen menu, or even the physical buttons on the TV itself.By familiarizing oneself with these options, users can easily troubleshoot any issues related to input selection and maximize the functionality of their LG TV. Whether it’s for entertainment purposes or for connecting multiple devices, having a clear understanding of where the input buttons are located will undoubtedly make the user’s TV experience much more convenient and enjoyable. So next time you find yourself searching for the input buttons on an LG TV, refer to this guide for a quick and hassle-free solution. In today’s world of advanced technology, smart TVs have become a popular choice for entertainment. LG Smart TVs offer a wide range of features and functionalities, but finding the buttons and controls on these sleek devices can be a bit daunting. Whether you’re a new LG Smart TV owner or just looking to familiarize yourself with the layout, this article will serve as a comprehensive guide to help you locate all the essential buttons on your LG Smart TV, ensuring a seamless and enjoyable viewing experience.Understanding The Basic Design Of LG Smart TVsLG Smart TVs are equipped with a sleek and minimalist design, aiming to provide an immersive viewing experience. Understanding the basic design of these TVs is essential to locate the controls easily.Most LG Smart TVs have a centralized control panel located at the bottom or back of the device. The TV’s power button is typically placed at the bottom of the panel, easily distinguishable by its unique icon. Additionally, the input button is usually positioned next to the power button, providing accessibility to switch between different input sources such as HDMI or USB.LG Smart TVs also come with a remote control that complements the physical buttons on the TV. The remote control is designed to have all the basic functions within reach, including power, volume, and channel buttons. Additionally, LG Smart TVs feature an intuitive on-screen menu, accessed through the provided remote control, allowing users to navigate through various settings and options effortlessly.Understanding the basic design of LG Smart TVs will enhance the overall user experience, making it easier to locate controls and access their desired features effortlessly.Locating The Power And Input ButtonsFinding the power and input buttons on an LG Smart TV can sometimes be a bit confusing, especially if you are new to the device. However, once you know where to look, it becomes quite simple. On most LG Smart TVs, the power button is usually located on the bottom edge of the screen, right in the center. It is often slightly recessed, making it easy to find by touch.Next to the power button, you will find the input button, which allows you to switch between different input sources. This button is typically labeled “Input” or may have an icon depicting an arrow pointing into a box. The input button is an essential control as it lets you connect various devices like gaming consoles, Blu-ray players, or streaming devices to your TV.If you can’t locate the power and input buttons on the bottom edge, they may also be located on the back of the TV or on the side. You can refer to your TV’s user manual for precise information on the location of these buttons.Discovering The Navigation And Menu ControlsNavigating through the menu options and controlling your LG Smart TV can be a seamless experience once you locate the navigation and menu controls. These controls are typically placed strategically on the TV remote or the panel of the TV itself.On the remote control, you will find the directional arrows that allow you to navigate up, down, left, and right within the menu options. These arrows are essential for moving across different settings and selecting your desired options. The central button, often referred to as the “OK” button, is used to confirm your selections or enter sub-menus.In addition to the directional arrows, the remote may include a dedicated “Menu” button. Pressing this button will take you directly to the main menu of your LG Smart TV, where you can access various settings, applications, and features.Alternatively, on some LG Smart TVs, you can find navigation and menu controls directly on the panel of the TV itself. These physical buttons allow you to perform the same functions as the corresponding buttons on the remote control.By locating and familiarizing yourself with the navigation and menu controls, you can effortlessly maneuver through the user interface of your LG Smart TV and customize your viewing experience.Finding The Volume And Channel ButtonsWhen it comes to watching television, adjusting the volume and changing channels is an essential part of the experience. LG Smart TVs provide convenient accessibility to these controls, allowing users to customize their viewing preferences effortlessly.To locate the volume and channel buttons on your LG Smart TV, start by examining your remote control. The volume controls are usually represented by ‚Ào+,Äô and ‚Ào-,Äô symbols, located on either side of a central button. This central button might also serve as a mute button, allowing you to quickly silence the sound.For changing channels, look for dedicated buttons labeled with numbers. LG Smart TVs typically include numeric buttons aligned horizontally, and by pressing the desired number, you can swiftly navigate to your preferred channel.Alternatively, some LG Smart TVs provide a scroll wheel on the remote control, allowing you to adjust the volume by simply rotating it. Additionally, the scroll wheel might function as a channel selector when pressed left or right.By familiarizing yourself with the position and functions of the volume and channel buttons, you can easily control your TV’s audio and switch between channels without any hassle.Exploring The Specialized Buttons And FunctionsLG Smart TVs come equipped with specialized buttons and functions that enhance the user experience and provide quick access to various features. Understanding these buttons and functions can greatly optimize your TV usage.One of the key specialized buttons on LG Smart TVs is the “Settings” button, often denoted by a gear icon. This button allows you to access the TV’s settings menu, where you can customize various aspects such as picture and sound settings, network configuration, and more.Another important button is the “Smart Home” button, which provides a convenient portal to LG’s Smart TV platform. This menu offers access to a plethora of apps, streaming services, and content options, ensuring you have an extensive entertainment library right at your fingertips.Additionally, LG Smart TVs often feature buttons dedicated to specific applications such as Netflix or Amazon Prime Video. These buttons allow for instant access to these popular streaming platforms without having to navigate through multiple menus.Moreover, some LG Smart TVs also come equipped with specialized buttons for gaming, enabling a seamless gaming experience by providing quick access to gaming features, settings, and even multiplayer options.By exploring the specialized buttons and functions on your LG Smart TV, you can unlock its full potential and enjoy a more personalized and efficient viewing experience.Locating The Playback Controls For Media ContentWhen it comes to enjoying media content on your LG Smart TV, it’s important to know where to find the playback controls. These controls allow you to pause, play, rewind, fast forward, and navigate through your favorite movies, TV shows, or videos.On most LG Smart TVs, the playback controls are conveniently placed on the remote control. Look for the buttons labeled “Play/Pause,” “Rewind,” “Fast Forward,” and “Stop.” These buttons are usually located near the center or bottom of the remote, making them easily accessible while holding the remote.If your LG Smart TV comes with a smart remote, you may also find touch-sensitive playback controls directly on the remote itself. These touch-sensitive controls provide a more intuitive and seamless experience, allowing you to control your media content with just a swipe or tap of your finger.In addition to the remote control, some LG Smart TVs also offer playback control options on the TV’s user interface. Depending on the model, you may find on-screen controls that allow you to adjust playback settings, such as playback speed or subtitles.Familiarizing yourself with the location of these playback controls will greatly enhance your overall viewing experience on an LG Smart TV.Using The Built-in Voice Control And Smart Assistant FeaturesLG Smart TVs are equipped with sophisticated voice control and smart assistant features that allow you to control your TV using only your voice. These convenient features can greatly enhance your TV viewing experience.To access the voice control feature, simply press the dedicated voice control button on your remote control. The built-in microphone will then activate, allowing you to give voice commands. You can perform various commands such as changing channels, adjusting the volume, launching apps, searching for content, and even controlling other smart devices connected to your TV.LG Smart TVs also offer compatibility with popular smart assistant platforms such as Amazon Alexa and Google Assistant. By linking your TV with these smart assistants, you can control your TV using voice commands through smart speakers or other compatible devices.The voice control and smart assistant features on LG Smart TVs provide a seamless and intuitive way to interact with your TV and access its features. Whether you want to change settings, search for content, or control your TV hands-free, these features make it easy and convenient.Troubleshooting Tips For Unresponsive Buttons On LG Smart TVsIf you find that the buttons on your LG Smart TV are not responding as they should, there are a few troubleshooting steps you can take to resolve the issue.First, check the batteries in your remote control. It is possible that the buttons are unresponsive due to a low battery charge. Replace the batteries with fresh ones and see if that resolves the problem.If the issue persists, try resetting the remote control. Locate the tiny pinhole on the back of the remote and use a paperclip or a similar object to press and hold the reset button for a few seconds. This can often restore functionality to the buttons.Another potential solution is to power cycle your LG Smart TV. Turn off the TV and unplug it from the power source for about 1-2 minutes. Then, plug it back in and turn it on again. This can sometimes resolve any minor software glitches that may be causing unresponsive buttons.If none of these steps work, it is recommended to contact LG customer support for further assistance. They can provide you with additional troubleshooting steps or arrange for a repair if necessary.FAQ1. Where can I find the power button on my LG Smart TV?The power button on most LG Smart TVs is typically located either on the front or side panel of the television set. It is usually marked with the power symbol (a circle with a vertical line through it). If you are unable to locate it, please consult your TV’s user manual for specific instructions.2. How do I access the menu on my LG Smart TV?To access the menu on your LG Smart TV, you can use either the dedicated menu button on your TV’s remote control or the on-screen menu button. On the remote control, look for the button labeled “Menu” or with an icon of three horizontal lines. Alternatively, you can press the Home button, which will also bring up the main menu.3. Where is the volume control on my LG Smart TV?The volume control on LG Smart TVs is typically located on the side or bottom panel of the TV, near the other control buttons. It is often marked with the “+” and “-” symbols to indicate volume up and down, respectively. If you prefer using a remote control, the volume buttons are usually clearly labeled and easily accessible.The Bottom LineIn conclusion, locating the buttons and controls on an LG Smart TV can be a bit challenging, as some models may have different layouts and options. However, by referring to the user manual or accessing the on-screen menu, users can easily locate and navigate through the various controls and buttons. Whether it’s adjusting the volume, changing channels, or accessing the settings, knowing where these controls are will enhance the overall user experience and enable users to fully enjoy the features and functions of their LG Smart TV. What do the buttons on your LG TV do? Here is a full explanation of LG TV remote control functions, and you can refer to it to get to know your LG TV remote control. LG TV remotes have evolved over the years, catering to various features and functionalities across their smart TV lineup. There are many variants of LG TV remotes, but they have similar functions. So, here I would like to take an LG TV Magic remote as an example to explain its functions. The LG TV Magic Remote is a significant variant of LG TV remotes, incorporating advanced features like voice and gesture control that change user interaction with LG Smart TVs. It has a sleek, modern design that’s compact and ergonomic, making it comfortable to hold and use. The button layout on the advanced remote is similar to that on the basic remote. From the top to the bottom, generally, the buttons are a numerical keypad, a directional pad, and colored buttons. Here are LG TV buttons explained: Power:turn on or off LG TV. TV: switch to TV. Numeric Pad: 1-9 number keys. Quick access: a long press to access the Quick Access menu. List: display the input or channel list. Audio description: access to control other devices via HDMI-CEC; long press to call AD/ASP. Volume control: turn up/down LG TV volume. Mute: put the LG TV into silent mode. Channel control: switch to a different channel. Home: access the LG TV homepage. Search: search for an app (on some magic remotes, the button marked as a microphone is used for voice control). Settings: access the Settings menu quickly. Directional pad: four arrow keys for moving up/down/left/right; the wheel button for scrolling pages up or down and confirming the selection. Back: go back to the previous page. Guide: check the programme. Netflix/Prime Video execution: launch the Amazon/Prime Video app quickly. Input:change the input source on LG TV (for example, when you connect your LG TV to a Roku Express, you can set the Roku device as the input source, then you can watch Spectrum on your LG TV). Colored buttons: there are four colored keys, namely red, green, yellow, and blue. They are used to access special functions in some menus. Movies: movies call. Pause: pause video playback. Play: continue to play the video. Or refer to the official explanation of LG Magic Remote. If you have an LG TV Magic Remote, to experience its functions, you need to pair it with your LG TV. The tutorial is displayed below. Step 1. Insert a pair of new batteries (alkaline batteries) into the LG TV remote. Step 2. Turn on your LG TV by pressing the power button on itself. On most LG TVs, the power button is located at the bottom, just under the LG logo. Step 3. Wafor 10 seconds. Step 4. Face your remote toward your LG TV and press the wheel button. If you see the message saying “Pairing is complete”, the pairing process is well done, and you can experience the LG TV remote functions. If your LG TV Magic Remote functions are not working, please initialize the remote first. To do so, you need to press the Home and Back buttons on the remote for 5 seconds at the same time. When the LED on the remote blinks 3 times, the remote is initialized, and you can press the Wheel button to re-pair the remote. If the remote still doesn’t work, you need to perform more troubleshooting steps detailed in Top 11 Fixes to LG TV Remote Not Working. Luckily, there is a quick solution. You can control your LG TV with your smartphone as long as the smartphone has a remote app. I would like to recommend you use the LG TV Remote app from BoostVision. Although the remote app doesn’t support voice control, it supports gesture control and allows you to launch an on-screen keyboard for quick text input. Moreover, with the virtual LG TV remote, you can save money on extra pairs of batteries. Download Remote for LG TV To use the remote app, you also need to pair it with your LG TV. Before carrying out the following steps, check if your LG TV and smartphone are connected to the same network. Otherwise, the TV won’t be detected. Launch the app on your smartphone and tap the connect icon in the upper-right corner. Choose your LG TV from the device list. Input the PIN code to connect the app to the TV. Once the connection is established, you can tap the buttons on your phone screen to control your LG TV. You can find basic and several modern functions on an LG TV Magic Remote, and each function is explained above. Refer to the explanation to get to know your LG TV remote. Note that a Magic remote needs to be paired with the LG TV and it can start